

# BURNER MAINTENANCE & CLEANING

Your LUXOR grill is made of non-rusting, non-magnetic stainless steel. After some initial usage, you will notice discoloration in some areas of the grill. It is a normal process caused by the high amount of heat produced by the burners. There are many different stainless cleaners available in the market, but be sure to use a mild cleaning product first, always scrubbing in the direction of the grain. If there are noticeable scratches in the stainless steel, use a dry 100 grit emery paper to sand the area. Sometimes, greasy specks collecting on the surface can look like rust. To remove these specks, use an abrasive pad together with a stainless steel cleaner. Remember to rub in the direction of the grain.

**NOTE:** The best way to maintain stainless steel is to wipe it down with a damp cloth. Excessive moisture causes a rust-like discoloration and may eventually require replacement. Never use steel "Brillo" pads or similar products as these will leave traces of material behind. This material will quickly rust. This rust is not a defect in the grill.

## ATTENTION

Before removing burners, gas supply must be shut off and the knobs turned to "OFF". Allow the grill to completely cool down.

## STAINLESS STEEL U BURNER

### GRILL BURNERS:

To begin, remove grill racks and radiant trays. Hold the burner, pull it up and slightly to the back of the unit. This way the burner head comes off the brass orifice at the front. Turn the burner sideways and remove the burner. Be careful not to block or upset the air shutter position.

### BURNER CLEANING::

Use a wire brush to clean the exterior of the burner. To clear stubborn scale, use a metal scraper. Clean any clogged ports with a straightened paper clip. Do not use a wooden toothpick as it may break off and clog the port. Use a flashlight to check the burner inlet for possible blockage. Shake out any debris through the air shutter. If you see any obstructions, use a metal wire coat hanger that has been straightened out.

### ORIFICE CLEANING:

After the burner has been removed, remove the orifice and hold a flashlight through the opening to check for possible blockage. Use a needle to clean any debris. use extreme caution so you do not enlarge the hole or break off the needle.